



# ES75/MC75 Terminal Installation Guide

ES75/MC75 Terminal is a compact modem for data and SMS transmission in GSM networks with the support of GPRS and EDGE standards. This short guide will show you how to connect and install the ES75/MC75 Terminal modem including programme for internet connection and sending SMS. For more information see the user's manual in the PDF file (Acrobat Reader) in the enclosed CD.

### **Security principles for ES75/MC75 Terminal**

- . Switch the modem off when you are in a hospital or near medical devices.
- . Switch the ES75/MC75 Terminal modem off when flying. Secure it so that it cannot be switched on inadvertently.
- . Switch the modem off when you are near petrol stations, fuel depots, chemical plants or blasting operations. The modem can disturb the operation of technical equipment.
- . Do not use ES75/MC75 Terminal in bathrooms and showers.
- . Prevent direct influence of heat sources such as heating radiators and do not expose it to direct insolation.
- . In order to avoid possible damage we recommend that you only use specified accessories such as power supply and original accessories.

ES75/MC75 Terminal complies with relevant European Union standards. Nevertheless, if sound and picture reception in your TV set or radio should be affected, check the quality of shielding with your TV set supplier.

**The warranty does not apply in the event of improper use!**

### **System requirements**

- . PC with min. Pentium 2, 350MHz
- . minimum 64 MB RAM and 3 MB free on HD
- . operation system Windows NT, 2000, XP
- . free USB port version 1.1 / 2.0 or COM port (USB connection is released for Windows XP)
- . CD-ROM or DVD

*Trade marks Microsoft, Windows 98SE, Windows ME, Windows 2000, Windows XP and Windows Explorer are registered trademarks of Microsoft Corporation.*

## **Installation**

1. Make sure that ES75/MC75 Terminal modem is not connected.
2. Close all the running programmes.
3. Insert the enclosed CD in the CD tray of your PC and wait until the welcome screen appears. If it does not do so automatically, start the installation manually: open Windows Explorer select CD-ROM drive and start the programme install.exe.
4. In the window select an interface you want to use: if you want to use ES75/MC75 Terminal via USB interface, push “Install USB driver” button. If you want to use it via RS232, push “Install modem driver” button.
5. Follow screen hints.

## **Operation instructions**

If it is not possible to connect, check your Firewall set-up. If during the connection to the internet via USB speed of 38400 kbps is displayed, it is only initial setting which does not affect the actual data transmission speed in any way.

During data transmission and surfing the net software problem in your PC (operation system drop-out, programmes mistakes) or a temporary problem in data transmission in the net of the operator can sometimes cause outage of ES75/MC75 Terminal. In such a case disconnect and connect to GPRS again. If this does not help, it is necessary to disconnect and again connect USB cable or restart PC.